


Warmaserv

Part No. 38162
Revised June 1996


Instruction Manual Model #5057



 **GOLD MEDAL®**
FUNFOOD EQUIPMENT & SUPPLIES

Cincinnati, OH 45241-4807 USA

SAFETY PRECAUTIONS

	 DANGER Machine must be properly grounded to prevent electrical shock to personnel. Do NOT immerse the equipment in water. Always unplug the equipment before cleaning or servicing.
	 WARNING ALWAYS wear safety glasses when servicing this equipment.
	 WARNING Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment. Make sure all machine switches are in the off position before plugging the equipment into the receptacle.
	 CAUTION Do NOT allow direct contact with this equipment and the general public when used in food service locations. Only personnel that are trained and familiar with the equipment should operate the equipment. Carefully read all installation instructions before operation.
	 CAUTION This machine is NOT to be operated by minors. Minors are classified as anyone under the age of 18.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.

OPERATING INSTRUCTIONS

ELECTRICAL REQUIREMENTS

Standard voltage for the WarmaServ is 120 volt, 60 cycle, single phase A.C. current. Your new unit is furnished with the proper size attachment plug for carrying this current, This unit requires a 15 amp circuit.

INSTALLATION

Remove all packing material. Position unit on a fairly level surface. Plug into a 15 amp circuit.

CARE AND CLEANING

When finished for the day, unplug the WarmaServ and clean product pan and false bottom with a soft cloth using water and a mild detergent. Using a damp cloth wipe off bottom pan, and all exposed areas. NEVER immerse anything but product pan and false bottom in water!

REPLACING HEAT LAMPS

	 DANGER Unplug your machine before servicing.
---	--

1. After allowing heat lamp to cool, simply unscrew bulb from its socket.
2. Replace with heat lamp rated 250 watt, 120 volt.

ORDERING SPARE PARTS

1. Identify the desired part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity desired.
3. Please include your model name and machine serial number (located on the machine nameplate) with your order.
4. Address all parts orders to:


Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:


(513) 769-7676
Fax: (513) 769-8500
E-mail: goldme19@eos.net

LIGHT ASSEMBLY

Item No.	Part No.	Description
1	49136	6-32 x $\frac{3}{16}$ " Pn. Hd. Ph.
2	38154	Name and Switch Plate
3	47202	Switch, Lights
4	76105	Thumb Screw, 10-24 x $\frac{3}{8}$ "
5	38156	Product Pan
6	38147	Bottom Pan
7	38152	U-Shape Base
8	38145	L-Shape Support
9	38148	End Plug
10	74144	10-32 x $\frac{1}{4}$ " RD. HD. PH.
11	40012	Porcelain Socket
12	38146	Lamp Shield
13	38161	False Bottom
14	47139	Heat Lamp
15	22038	Lead-In Cord with 15Amp Plug
16	87194	Strain Relief
	38153	Light Assembly



WARMER WIRING DIAGRAM



WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-428-2676 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



GOLD MEDAL PRODUCTS COMPANY
10700 Medallion Drive
Cincinnati, OH 45241-4807 USA