

Part No. 88174
October 2008

Roller Grill

Model #8123

Instruction Manual



 **GOLD MEDAL**®
FUNFOOD EQUIPMENT AND SUPPLIES

Cincinnati, OH 45241-4807 USA

SAFETY PRECAUTIONS

	⚠ CAUTION This equipment is designed and sold for commercial use only. This equipment is not to be used by the consumer in home use. Do not allow direct contact of this equipment by the public when used in food service locations. Only personnel trained and experienced in the equipment operation may operate this equipment. Carefully read all installation instructions before operating the equipment.
---	---

	⚠ WARNING Always wear safety glasses when servicing this equipment.
---	--

	⚠ WARNING Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment.
---	---

	⚠ DANGER Machine must be properly grounded to prevent electrical shock to personnel. Do NOT immerse the equipment in water. Always unplug the equipment before cleaning or servicing.
---	--

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.

INSTALLATION INSTRUCTIONS

Note: Make sure to have all employees read the instruction manual thoroughly before operating this machine.

Checking Shipment

Unpack all cartons and check thoroughly for any damage that may have occurred during transit. Damage claims should be filed immediately with the transportation company. Gold Medal is not responsible for damage that occurs in transit.

Electrical Requirements:

The following power supply must be provided:

Model No. 8123: 120 VAC, 60 Hz.

	⚠ DANGER Machine must be properly grounded to prevent shock in case of electrical problems. Wall receptacle must be wired as shown on the receptacle. Failure to wire properly will void the warranty and can result in damage to motors, elements, relay, lights, etc.
--	--

Your electrician must furnish sufficient current for proper machine operation. It is Gold Medal Products Company's recommendation that this machine be connected to a fused circuit by itself. Failure to wire properly will void the warranty and can result in damage to the heat elements, light, motor and etc.

It is Gold Medal Products Company's recommendation that this machine be plugged directly into a wall outlet. The use of extension cords is not recommended due to safety reasons and the popper's performance will be sacrificed/reduced.

NOTE: These instructions apply to all machines manufactured after 4/1/1975 and supercedes any sticker or wiring instructions you may have received. Failure to wire properly will void the warranty and can result in damage to the blower, heat element, lights, etc.

OPERATING INSTRUCTIONS

Controls and their functions

ON/OFF SWITCH

Flipping this switch to the "ON" position energizes the motor that turns the rollers. This switch can be used alone or with the heat turned on.

HEAT CONTROL

Turning this control counter-clockwise increases the amount of heat to the rollers. There are 3 sets of these controls, 1 for each set of rollers

Care and cleaning

The stainless steel body of the grill is easy to keep clean. Usually a damp cloth will remove all dirt and grease spots. NEVER USE ABRASIVES on the stainless steel body. The glass should always be clean and sparkling. Remember the inside of the glass must be cleaned too.

MAINTENANCE INSTRUCTIONS

	⚠ CAUTION THE FOLLOWING SECTIONS OF THIS MANUAL ARE INTENDED ONLY FOR QUALIFIED SERVICE PERSONNEL WHO ARE FAMILIAR WITH ELECTRICAL EQUIPMENT. THESE ARE NOT INTENDED FOR THE OPERATOR.
---	---

	⚠ WARNING Adequate eye protection must be used when servicing this equipment to prevent the possibility of injury.
---	---

	⚡ DANGER Do NOT immerse the equipment in water. Unplug your machine before servicing.
---	--

ORDERING SPARE PARTS

1. Identify the desired part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity desired.
3. Please include your model name and machine serial number (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:
(800) 543-0862
(513) 769-7676
Fax: (513) 769-8500
E-mail: info@gmpopcorn.com
Web Page: www.gmpopcorn.com


PARTS LIST – 8123 ROLLER GRILL

Model # 8123

Item Part

No.	No.	Description	Quantity
1	88228	Outer Spacer	15
2	88229	Inner Spacer	15
3	88053	Assembly Bracket Weldment	3
4	88054	Element Support	3
5	88055	Insulator Board	3
6	88056	Conductor Plate	3
7	88093	Bottom Plate	1
8	88097	Drip Pan	1
9	88098	Control Panel Sticker	1
10	88123	90 Watt Heat Element	18
11	88133	Right Side Plate Weldment	1
12	88134	Left Side Plate Weldment	1
13	42532	DSPT Rocker Switch	3
13	87085	Lead-In Cord	1
14	87347	Teflon Bearings	36
15	87297	Heat Control	3
16	87353	Drive Sprocket	3
17	87532	Drive Motor	3
19	88232	Roller Assembly	18
20	88094	Back Plate	1
21	88102	Drive Chain	3
22	87988	Idler Sprockets	15
23	77521	8-32 x ¾ slot hx hd	15
24	68707	Idler Bracket Assy	3
25	68734	Spring	3
26	68745	Idler Front Plate w/Studs	1
27	40571	Idler Bracket w/Studs	1
28	83106	Idler Pivot	3
29	87988	Idler Sprocket	3

WIRING DIAGRAM



WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-543-0862 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



GOLD MEDAL PRODUCTS COMPANY

10700 Medallion Drive

Cincinnati, Ohio 45241-4807 USA

www.gmpopcorn.com

Phone: 1-800-543-0862

Fax: 1-800-542-1496

© The text, descriptions, graphics and other material in this publication are the proprietary and exclusive property of Gold Medal Products Company and shall not be used, copied, reproduced, reprinted or published in any fashion, including website display, without its express written consent.