


TABLE TOP GRILL

Instruction Manual Models #8200



SAFETY PRECAUTIONS

	⚠ DANGER Machine must be properly grounded to prevent electrical shock. Do NOT immerse this unit in water. Do not use excessive water when cleaning. Always unplug the equipment before cleaning, or servicing.
	⚠ WARNING Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment. Make sure all machine switches are in the OFF position before plugging the equipment into a receptacle.
	⚠ WARNING Adequate eye protection must be used when servicing this equipment to prevent the possibility of injury.
	⚠ WARNING NEVER put your fingers or any object into the heating area. We do NOT assume any liability for injury due to careless handling or operation of this equipment.
	⚠ CAUTION This equipment is designed and sold for commercial use only. This equipment is not to be used by the consumer in home use. Do not allow direct contact of this equipment by the public when used in food service locations. Only personnel trained and experienced in the equipment operation may operate this equipment. Carefully read all installation instructions before operating the equipment.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.

FENCE GRILL INSTALLATION


CHECKING SHIPMENT

Unpack the shipping crate and check thoroughly for any damage which may have occurred in transit. Any claims should be filed immediately with the transportation company.


ELECTRICAL REQUIREMENTS

Voltage for your grill is 120 Volt, 60 Cycle, single phase. The 8200 will draw a maximum of 14.33 amp.. Your electrician must furnish sufficient current for the proper operation of your machine. We recommend that this machine be installed on a dedicated line.

NOTE: These instructions apply to all machines manufactured after 3/20/2004.



OPERATING INSTRUCTIONS



CONTROLS AND THEIR FUNCTIONS

HEAT CONTROLS

(1) Heat control. This heat control has a positive OFF and are variable from low to high.

ON/OFF SWITCH

Provides power to the controls with a built in pilot light to indicate that there is power to the unit.

EASY STEPS FOR USING UNIT

1. Wipe grill clean prior to operation by using a damp washcloth.
2. Turn the on / off switch on. Turn heat controls clock-wise to high position.
3. Pre-heat grill for 15 minutes.
4. Place product on grill..
5. Cook for 20-30 minutes and check product temperature with thermometer provided. (Should be 150 Degrees F.) Adjust heat as necessary to raise the temperature of the food to 150 degrees Fahrenheit.
6. Carefully remove and serve product.


CARE AND CLEANING

The stainless steel body of the Fence Grill is easy to keep clean. Usually a damp cloth will remove all dirt and grease spots. NEVER USE ABRASIVES on the stainless steel body, cooking surface, or fence.

Cleaning Procedure:

Turn Grill off and allow to cool for at least 2 hours before starting the cleaning procedure.

1. Unplug grill
2. Empty drip pan.
3. Wash drip pan as necessary with soap and water.
4. Clean stainless steel portion of unit with damp cloth and dry.
5. Clean cook top Watchdog Concession Equipment Cleaner. (Gold Medal Item #2580)



MAINTENANCE INSTRUCTIONS

	⚠ DANGER Machine must be properly grounded to prevent electrical shock to personnel. Do NOT immerse in water. Always unplug the equipment before cleaning or servicing.
	⚠ WARNING Adequate eye protection must be used when servicing this equipment to prevent the possibility of injury.
	⚠ CAUTION THE FOLLOWING SECTIONS OF THIS MANUAL ARE INTENDED ONLY FOR QUALIFIED SERVICE PERSONNEL WHO ARE FAMILIAR WITH ELECTRICAL EQUIPMENT. THESE ARE NOT INTENDED FOR THE OPERATOR.

ORDERING SPARE PARTS

1. Identify the needed part by checking it against the photos, illustrations, and/or parts list.
2. When ordering, please include part number, part name, and quantity needed.
3. Please include your model name, serial number, and date of manufacture (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807
(800) 543-0862
(513) 769-7676
Fax: (513) 769-8500

or, place orders online at:

E-mail: info@gmpopcorn.com


Web Page: www.gmpopcorn.com

PARTS LIST – FENCE GRILL

Model # 8200

Item #	Part #	Description	Qty.
2	55395	Lighted Rocker Switch	1
3	85133	Control Label	1
4	87049	Heat Control Knob	1
5	17096	Right Side Plate	1
6	85134	Cook Plate	1
7	17095	Left Side Weldment	1
8	85124	Drip Pan	1
9	87085	Lead-In Cord Assy.	1
13	87297	Heat Control	1
14	17098	Rear Panel	1
15	17097	Front Plate	1
16	17099	Control Guard	1
18	85040	Element Clamp	4
19	85027	Element Clamp Retainer	4
20	85108	Heat Element	2
21	17100	Control Box	1
22	42616	4" NSF Legs	4
23	17102	Bottom Plate Weldment	1
24	50013	Magnets	2

Electrical Schematic



WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-543-0862 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



GOLD MEDAL PRODUCTS COMPANY

10700 Medallion Drive

Cincinnati, Ohio 45241-4807 USA

www.gmpopcorn.com

Phone: 1-800-543-0862

Fax: 1-800-542-1496

© The text, descriptions, graphics and other material in this publication are the proprietary and exclusive property of Gold Medal Products Company and shall not be used, copied, reproduced, reprinted or published in any fashion, including website display, without its express written consent.