




# DAILY OPERATION




Check chemical levels in containers




Flip "ON/OFF" switch to "ON" position




Wait for temperature gauge to read 150°F/66°C.




Prescrap wears and load into rack. Do not overload rack.



Load rack into dishwasher



Close door, press and hold "START" button for 1 second. Green in-cycle light will come on




Final rinse temperature should be a minimum of 180°F/82°C during the final rinse.


Wash cycle is extended if the final rinse water is not up to 180°F/82°C.

CYCLE IS COMPLETE WHEN GREEN LIGHT GOES OUT.


# DRAINING THE MACHINE




Flip "ON/OFF" switch to "OFF" position



Open door, and remove standpipe from tank.



Press and hold "DRAIN" button for 1 second to begin drain cycle.



Perform regular cleaning and replace standpipe when drain cycle has completed.